
South Bend

THE BEST IN RODS • REELS • LINES • LURES

REEL REPAIR BULLETIN #4-1

Sup-matic

606-G 707-G



PART N	D. NAME	PRICE	PART NO). NAME	PRICE	PART NO.	NAME	PRICE	PART NO.	NAME	PRICE
1G 7	Housing Cover Screw	\$4.25 .10	29	Gear Change Shaft Adjustin Shims	g \$.10		-up Bail Button Lever Screw	\$.20 .10	•	Compression Nut Spring	\$.10 .15
	Worm Gear Cover Ring Ball Plate Guide	1.25 .35 .10	1/31	Driving Shaft Bushing Smooth Wind Gear	.10 .75	1/64 Bail	Plate Screw Spring	.25 .10	84 Upper	Washer Washer	.10
11 12 14	Ball Bearings Upper Threaded Ring Triple Gear Assembly —	.10 .60	1/37	Roller Slide Slide Screw Main Shaft Assembly	.35 .10 .75	1/66 Bail	Holder Trip Lever	.35 .10 .10	86 Upper	Fiber Friction Washer	
19	707-G ONLY Washer	1.20 .10		Gear Change Button 707-G ONLY	.20	69 Anti	Trigger Spring	.65	1/88 Wing	Nut Retaining Screw	.35
19 bis	Circlip THRU 29 FOR 707-G REEL	.10		Handle Complete 707-G ONLY	1.90	71 Anti	i-reverse Dog i-reverse Dog Spring		Asi	ge Capacity Spool — iembled	3.00
20 21	Washer Low Speed Gear	\$.10	l	Handle Arm — 707-G ONLY Handle Knob Shaft	1.60 .10	73 Ant	-reverse Retaining S i-reverse Dog Screw	.10	1/75A-B Sme Ass	all Capacity Speel — embled	3.00
23	Gear Shift Washer High Speed Gear	.15 .45	1/53 I 1/49B F	Drum Iandle Knob	2.75 .20	1/75B Spoo	ol, Large Capacity ol, Small Capacity	.75 .75		R 606-G REEL ONLY	
2/24 3/24	High Speed Shaft Low Speed Shaft Gear Pawl	1.15 .75 .35	1/55	Lock Nut Pick-up Bail Assembly Pick-up Roller	.10 1.25 .20	78 Drag	g Spring g Click Screw	.10 .10	514 Doubl	and Shaft Assembly • Gear Assembly r Washer	\$2.00 1.00 .15
	Gear Pawl Pin Gear Change Spring	.10 .10	1/58 I	Roller Lock Nut Shock Absorber	.10 .10		ol Shaft g Nut	.50 .25	1/45 Handi	e Arm (not shown) e (Crank Assembly)	1.20 1.50

DISASSEMBLY and ASSEMBLY INSTRUCTIONS

- Hold the reel with the crank handle 1/49 pointing at you. Turn the whole handle assembly clockwise and unscrew it.
- Remove spool 1/74 or 1/75 by pressing the spool inward and then turning it in any direction about 45° to free it.
- Turn the reel 90° and unscrew cover screw 7. Remove the plate and the housing is open for washing, oiling and greasing.

NOTE: Gear Change Button No. 42B must be slightly heated before unscrewing.

- Unscrew slide retaining screw 1/37 and you can remove the main shaft 1/38, roller slide, 1/36 and smooth wind gear 1/31. Do not drop brass bearing washer 20.
- By pushing the Circlip 19 bis sideways out from the shaft groove, you can disassemble the intermediate gear and also the crank shaft and gear assembly 24.
- 6. Reverse procedure to assemble.

NOTE: When ordering parts, give reel part name, reel number and model.